


TO SUNAI



TC103 Pro

CAN FD LIN FlexRay



CAN FD/CAN LIN FlexRay

TC Pro

CAN/CAN FD LIN FlexRay
CAN/CAN FD CAN Kbps
- Mbps CAN FD Mbps LIN
- Kbps FlexRay

TC Pro

PC PC

Windows

ARXML

TSMaster DBC LDF XML
UDS ECU CCP/XCP

- us
- Windows
- CAN/CAN FD LIN FlexRay
- DIDO * AIAO *
- CAN Kbps- Mbps CAN FD Mbps
- LIN
- CAN Ω
- CAN Self-ACK
- FlexRay Ω
- BLF ASC /
- API

PC	RJ
CAN	DB
LIN/FlexRay	DB
IO	DB
Windows	

CAN	CAN . A B	ISO	-	Kbps	Mbps
CAN FD	ISO	ISO	CAN FD	Kbps	Mbps
FlexRay	FlexRay channel (A and B)				
LIN	LIN .	.x	Kbps		
	us				
	CAN FlexRay				
	CAN/FlexRay	DC	V		
DIDO	DI - V	Vref: - . V			
	DO	V	V/ V		
AIAO	AI - V	AO - V			
	DC	W			
	-				
	* * mm				